

# Vector Frame Master 20ft Modular Backwall Kit 26

## VF-K-26

The 10ft x 20ft inline Vector Frame<sup>®</sup> Kit 26 is a robust modular exhibit that has a lot of bells and whistles! Extrusion frames are coupled with push-fit SEG graphics to create a sleek, seamless appearance. Functionality is delivered with a storage closet, slot wall for hanging merchandise and a monitor mount to hang a TV for promotional use.



Door located on this wall



## Features and benefits:

- 50mm silver extrusion frame
- Single-sided SEG push-fit fabric graphics
- 4'w x 4'd Storage closet for convenient storage with locking door
- Monitor mount supports 32"-55" monitors with a 40 lb. max capacity
- Three Lumina 2 LED lights
- Slot wall for product displays
- Ships freight in a wood crate
- Slot wall has a 30 lb. max capacity
- Lifetime hardware warranty against manufacturer defects

## dimensions:

### Hardware

Assembled unit:  
228.35" w x 94.49" h x 51.18" d  
5800mm(w) x 2400mm(h) x 1300mm(d)

Approximate weight:  
425 lbs / 193 kg

### Graphic

Refer to related graphic template for more information.

Visit:  
<https://www.theexhibitorshandbook.com/download-graphic-templates>

### Shipping

Packing case(s):  
1 HALF-WOODCRATE

### Shipping dimensions:

WOOD-CRATE:  
101" l x 31" h x 52.75" d  
2566mm(l) x 788mm(h) x 1340mm(d)

Approximate total shipping weight:  
693 lbs / 314 kg

## additional information:

Graphic material:

Dye-sublimate SEG push-fit fabric graphics

When included in a larger kit, a different packaging solution will be listed to accommodate all contents of the kit. Individual packaging no longer provided.

Lighting Power Requirements:

Total wattage needed:	Total ampage needed:	Voltage used:
36 watts	3.6 amps	100-240 volts



This product may include the following materials for recycle:  
aluminum, select wood, fabric, cardboard, paper, steel, and plastics.

2 person assembly recommended:



We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

# Included In Your Kit

Tools, Components, & Connectors



HEX-KEY-SET x1



FABRIC STEAMER-ES x1




5MM-ALLEN-T x1




VF-FCDOOR-50MM-1200-L x1




LUM-LED2-ORL-B x3




PH1-2310-L-L x1




PHFC2-2100-L1-MCB9 x2




PHFC2-2400-L1-MCB9 x2




LP-PS-1200-1200 x2




PHFC4-2400-MCB9-MCB9 x1




PHFC2-1200-MCB9-MCB9 x2




PHFC2-1500-MCB9-MCB9 x4



PHFC2-1200-L-L x2



SW-FOOT-500-LN x1




CB9 x8

# Included In Your Kit


Tools, Components, & Connectors




FREESTANDING-SPLIT-MM-2 x1




FC-2386 x8




CBE-50 x4



PHFC2-2400-MCB9-MCB9-SIDE x3




PM2S2-2400 x4




IB2 x2

# Included In Your Kit


Graphics




VF-K-26-A-G x1



VF-K-26-B-G x1




VF-K-26-C-G x1




VF-K-26-D-G x1

Liners



VF-K-26-K-G x1




VF-K-26-J-G x1




VF-K-26-I-G x1



VF-K-26-H-G x1



VF-K-26-G-G x1



VF-K-26-F-G x1




# Kit Components

VF-K-26


50MM CLOSET



VECTOR BACKWALL





FREESTANDING-SPLIT-MM-2






# Closet Assembly

For this step you will need:




Slide FC Channels into the outside channels of the PM2S2 facing the door frame.




# Closet Assembly


For this step you will need:



Using the 5mm Allen-T attach the PHFC2s at the top and bottom of your door frame to two of your PM2S2s.





Using the 5mm Allen-T attach the PH1s on your door frame to two of your PM2S2s.




Door frame comes assembled  
\*DO NOT DISASSEMBLE\*

# Closet Assembly

For this step you will need:





Attach the back frame of the closet together using the Allen Tool and the CB9 Connectors.




# Closet Assembly


For this step you will need:



Inside the PHFC2s are cam locks.





These will attach the PHFC2 to the side of the PMFC2. So you can connect your completed door frame with the back frame.




# Closet Assembly


For this step you will need:



Slide FC Channels into the outside channels of the PM2S2 facing the door frame.





Using the 5mm Allen-T attach the PHFC2s at the top and bottom of your door frame to two of your PM2S2s.




# Closet Assembly


For this step you will need:



Inside the PHFC2s are cam locks.




These will attach the PHFC2 to the side of the PMFC2. So you can connect your completed door frame with the back frame.






# Closet Assembly


For this step you will need:



Slide the lock panels into the PM2S2 then using the Allen-T lock the panels into place.





Using the bottom clip attached to the light slip the plastic bottom into the channel on top of the lock panel.






# Graphic and Back Liner Application


For this step you will need:



Place the FCE-2 part of the graphic into the outer channels of the PHFC2.





Place the FCE-2 part of the graphics into the FC channel that's attached to the PM2S2 extrusions.




# Liner Application


For this step you will need:



Place the FCE-2 part of the liner into the outer channels of the PHFC2.





Place the FCE-2 part of the liner into the FC channel that's attached to the PM252 extrusions.




# Backwall Assembly


For this step you will need:




Completed Step



Attach the backwall together using the Allen Tool and the CB9 Connectors.





Attach the backwall together using the Allen Tool and the IB2 Connectors.




# Backwall Assembly

For this step you will need:




Completed Step

17




Attach the backwall together using the Allen Tool and the CB9 Connectors.

18




Slide the baseplate on the side of the extrusion in the channel then screw in place with the thumbscrew.



# Backwall Assembly

For this step you will need:



Completed Step


19



Using the bottom clip attached to the light slip the plastic bottom into the channel on top of the PHFC2.

19




19






# Closet and Backwall Assembly


For this step you will need:



Inside the PHFC2s are cam locks.





These will attach the PHFC2 to the side of the PMFC2. So you can connect your closet and backwall.




# Backwall Graphic Application


For this step you will need:




Completed Step



Place the FCE-2 part of the graphic and liner into the outer channels of the PHFC2.



# Completing your Kit



To complete assembly see attached  
monitor mount instructions.



# Free Standing Split Monitor Kiosk

## FREESTANDING-SPLIT-MM-2

The Freestanding Monitor Kiosk supports large screen LCDs and plasma flat panel monitors for use in trade show exhibits, at events and in all types of interior spaces. Video is an excellent way to show your large scale products, solutions and explain your services face to face. This elegant, stand-alone display supports a TV with a maximum weight of 40 lbs.



### features and benefits:

- Standard black aluminum post and base
  - Quick to set up
  - Weighted base for added stability
  - Supports large monitor 32-70"
  - Max TV weight = 40 lbs
  - Monitor not included
- Kit includes: Top pole, bottom pole, counter, base, monitor mount assembly
  - Lifetime hardware warranty against manufacturer defects

### dimensions:

Hardware

Graphic

Assembled unit:  
26.25" w x 75.25" h x 23.56" d  
667mm(w) x 1912mm(h) x 599mm(d)

Refer to related graphic template for more information.

Approximate weight:  
45 lbs / 21 kg

Visit:  
[www.exhibitors-handbook.com/graphic-templates](http://www.exhibitors-handbook.com/graphic-templates)

Shipping

### additional information:

Packing case(s):  
1 Box(es)

Shipping dimensions:  
34" l x 28" h x 7" d  
864mm(l) x 712mm(h) x 178mm(d)




When included in a larger kit, a different packaging solution will be listed to accommodate all contents of the kit. Individual packaging no longer provided.

Approximate total shipping weight:  
50 lbs / 23 kg

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

# Included In Your Kit

Tools, Components, & Connectors



TOP POLE x1

BOTTOM POLE x1

COUNTER x1


FREESTANDING-SPLIT-EXT-2 x1

FREESTANDING-SPLIT-EXT-4 x1



# Exploded Diagram

FREESTANDING-SPLIT-MM-2

FREESTANDING -SPLIT-EXT-2



FREESTANDING-SPLIT-EXT-4




# Kit Assembly

## Step by Step

### Step 1.

Gather the components to build the bottom section. Use the Exploded View for part labels.




### Step 2.

Gather the components to build the top section. Use the Exploded View for part labels.



### Step 3.

Gather the components to install counter. Use the Exploded View for part labels.



### Step 4.

Gather the components to attach monitor bracket. Use the Exploded View for part labels.

Reference Connection Method(s) 1 for more details.




# Kit Assembly

## Step by Step

### Step 5.

Gather the components to build the monitor supports. Use the Exploded View for part labels.



### Step 6.

Gather the components to attach supports to the monitor. Use the Exploded View for part labels.



### Step 7.

Setup is complete.



### Step 8.

2" & 4" EXTENTION HARDWARE

The extension parts help extend monitor 2" or 4" out from the stand, if needed for placement behind display or any other obstruction. More details follow this page.




# Kit Assembly

## Step by Step

### Step 9.

Gather the components to attach 2" monitor supports. Use the Exploded View for part labels.




FREESTANDING -SPLIT-EXT-2



### Step 10.


Gather the components to attach 4" supports to the monitor. Use the Exploded View for part labels.

FREESTANDING -SPLIT-EXT-4




# Connection Methods

## Connection Method 1: ATTACH MOUNT TO STAND



First, attach bracket to stand using both hands to hold in place. Once front and back brackets are lined up, insert bolts. Tighten to ensure monitor mount does not move. Do not over tighten, may damage stand or hardware. Monitor should be attached last. Do not try to attach brackets with monitor attached. This may lead to damaging monitor or injury.

## Connection Method 2: ATTACH 2" FREESTANDING-SPLIT-EXT-2



First, attach bracket to stand using both hands to hold in place. Once front and back brackets are lined up, insert bolts. Tighten to ensure monitor mount does not move. Do not over tighten, may damage stand or hardware. Monitor should be attached last. Do not try to attach brackets with monitor attached. This may lead to damaging monitor or injury.

## Connection Method 3: ATTACH 4" FREESTANDING-SPLIT-EXT-4



First, attach bracket to stand using both hands to hold in place. Once front and back brackets are lined up, insert bolts. Tighten to ensure monitor mount does not move. Do not over tighten, may damage stand or hardware. Monitor should be attached last. Do not try to attach brackets with monitor attached. This may lead to damaging monitor or injury.